

HI10000 INSTALLATION DIAGRAM WITH ACID INJECTION SYSTEM

PARTS AND ACCESSORIES PROVIDED BY HANNA

- HI10000 FERTIGATION SYSTEM AS ORDERED
- EXTERNAL FLOW SWITCH WITH 3" COLLAR FOR 3" LINE
- 2 EACH 4", 8 BOLT FLANGES
- ACID INJECTOR, ACID TUBING TO AND FROM FERTIGATOR, PH ELECTRODE FOR ACID, FOOT VALVES, ETC.

PROVIDED BY CUSTOMER

- ALL PVC PIPING AND FITTINGS, VALVES, ETC. TO AND FROM FERTIGATOR
- STRAIGHT RUN OF 3" LINE PRIOR TO FERTIGATOR FOR FLOW SWITCH. AT LEAST 5' OF STRAIGHT RUN.
- 1 OUTLET PROVIDING **208 VAC 3 PHASE POWER**. MUST SPECIFY BEFORE SHIPMENT IF POWER IS 240 3 PHASE.
- 2 OUTLETS PROVIDING 115 VAC SINGLE PHASE POWER. RECOMMEND 1 BOX WITH 4 OUTLETS.
- FERTILIZER AND ACID TANKS, FERTILIZER TANK FILTERS, AND HOSES FROM FERTILIZER TANKS TO FERTIGATOR

